







ANS21131



Item	code	Description
2A1	A19300204A1	CAP ASM.
83	JUS0612BF	UM.HD.BOLT
81	D19308101	EXHAUST PLATE
82	D16500401	EXHAUST FILTER
1	JHS0835BWF	HEX.SOC.HD.BOLT
2	A19300204	CAP
3	F19300301	PISTON STOPPER
4	G19300401	SPRING
5	D19300501	WASHER
6	ID5700W300	O-RING
7	F19300702	PISTON HEAD VALVE
14	ID6940W310	O-RING
9	F19300902	SEAL
10	ID5560W570D80	O-RING
12A1	H19301201A1	DRIVER ASSEMBLY
13	C19301303	CYLINDER
14	ID6940W310	O-RING
15	F19301502	COLLAR
16	IB0754W353D90	O-RING
17	ID7060W570	O-RING
18	F19301802	GASKET
59	JHS0630BWF	HEX.SOC.HD.BOLT
72	JFW061920	FLAT WASHER
35	F19906701	SPACER
19	A19901901	BODY
58	F15403202	RUBBER GRIP
57	JRP030P30	ROLLED PIN
65	ID0680W190D80	O-RING
22	F19302203	UP BUMPER
23	F19302303	BOTTOM BUMPER
24	ID7587W262	O-RING
25	E19302501	NOSE
27	G19009001	SPRING
28	D19302801	UPPER SAFETY LEVER
29	D19302902	SAFETY LEVER
30	JHS0512BWF	HEX.SOC.HD.BOLT
31	JFW051313	FLAT WASHER
69A8	F16508201A8	SWITCH ASM.
89	G19005801	SPRING
86A2	F16508601A2	TRIGGER ASSEMBLY
86A1	F16508601A1	TRIGGER ASSEMBLY
90	F19006501	TRIP GUIDE
91	G17509101	SPRING
92	E19006802	CONTACT TRIP BLOCK
47	JHS0522BF	HEX.SOC.HD.BOLT
45	F19304503	NOSE COVER
53	G19005301	SPRING
54	F19305401	MAGAZINE COVER
56	H19305601	SPACER

55	D19005501	STOPPER
39	JFS0430B	FLAT HD. BOLT
43	JFS0422B	FLAT HD. BOLT
42	JFS0418B	FLAT HD. BOLT
41	JLN0400E	LOCK NUT
33	D11603304	NAIL GUIDE LINER
84	JSS0404BF	SET SCREW
34	B19303402	MAGAZINE
26	JHS1225SF	HEX.SOC.HD.BOLT
73	H19303902	BRACKET
36	JFW061320	FLAT WASHER
37	JHS0614BWF	HEX.SOC.HD.BOLT
32	JSW061012	SPRING WASHER
46	JHS0612SF	HEX.SOC.HD.BOLT
50	JBP040P20	BALL PIN
51	F19005102	ROLLER
52	G19005203	SPIRAL SPRING
44	JUS0512BF	UM.HD.BOLT
38	JLN0500E	LOCK NUT
36	JFW061320	FLAT WASHER
59	JHS0630BWF	HEX.SOC.HD.BOLT
48	F19304801	SLIDE BLOCK
49	E19304901	PUSHER
34A3	B19303402A3	MAGAZINE ASM.
84A	F19308403A	HANDLE ASM.